

Has your Rolex watch stopped working? Have you tried to replace the battery? Replacing your watch battery and figuring out the proper watch battery fixing your watches battery is extremely simple if you follow these exact steps.



First, you turn your watch over so the face is facing downward. After this is done, you should be able to see the back of the watch and not be able to see the face anymore. Make sure you place the face of the watch on a washcloth or soft surface so the glass is not scratched. Following make sure you remove the water guard that is on every watch. This piece of your watch ensures that interior parts of your watch are not damaged forever.



Secondly, you should remove the back cover of the watch. This requires screwing the back off the watch. If your watch is a screw off watch, then your watch will have ridges and you must use a watch wrench to twist the back cover off. If the back of your watch is pop off, you must place the screwdriver between the watchcase and the back.



Thirdly, you locate the watch battery, which appears to be a small silver disc. Before removing the battery, make sure you pay attention to the side of the battery that is facing upwards because you will need to know how to properly install your new battery. To release the actual battery you must carefully place your screwdriver under the battery to lift it upwards. Screws hold down some Rolex watch batteries so you must use a small screwdriver to loosen the screws and remove the battery.

Fourth, you must remove the battery with a set of tweezers very carefully. During this step, if you do not know the type of watch your battery uses, you can look on your old battery for the model type.



Fifth, you put the new battery in the same place that the old battery was with the correct side facing up. If screws held your battery in, then replace the screws after placing the battery in its proper location.



Sixth, place the water guard back on the watch properly to ensure that water does not enter into your watch and cause permanent damage.

Lastly, press down on the watch back if your watch includes a snap back. When you hear the click, you know your watch back is closed properly. If it's a screw back, place the back on the watch and use the watch wrench to tighten the back on the watch to ensure its put into place and installed properly.

If you follow these easy steps, your watch should be fully functioning with this new battery and damage free. If your watch is not functioning good as new, repeat these steps over again. If they do not work after that, take your watch to a watch specialist or to a Rolex store to see what the problem is because it is most likely more than the watch battery.